



NOTES:

SET COBBLE IN 4" THICK CONCRETE
 MAINTAIN 1/2" SPACE BETWEEN
 ROCKS. GROUT ALL JOINTS, REMOVE EXCESS
 CONCRETE IN JOINTS. TROWEL TO 1/2" DEEP
 BETWEEN JOINTS.

CONCRETE MIX TO BE:
 6 SACK WITH PEAGRAVEL/SAND SLURRY MIX

COBBLE STONE PATTERN RANDOM PLACED WITH
 FLAT SIDE UP

DATE: <u>MARCH 2008</u>	COBBLESTONE MEDIAN DETAIL	SCALE: <u>NONE</u>
Signature on File <u>LANDSCAPE MGR.</u>		PLT DRAWING NO. <u>007</u>
LANDSCAPE DIVISION		CITY OF PALM DESERT